

# SMI FREEDOMX STICK

The FreedomX is SMI's variable air LowE stick. Utilizing central (hill) air and two different air flows, the stick is configured to your snow quality, weather and production targets. Run the stick on low to utilize it as a LowE stick or flip on the Air Blast for marginal conditions.

The FreedomX's five steps adjust with four water steps and two air steps.


Additional air is used in steps 1-2, and reduced for steps 3-5 to the LowE set point. Allowing your resort to balance energy efficiency with snowmaking production goals. Adjusting steps is as easy as turning a handle with SMI's intuitive revolver valve for manual equipment. SMI also offers automated solutions for our FreedomX line.

The FreedomX is simple to operate and maintain and a versatile solution for your resort. Contact your local SMI representative for more information.




# FREEDOMX STICK HIGHLIGHTS


## 1. HEAD



## 2. MANUAL REVOLVER VALVE



## 3. AUTO VALVE



### CONFIGURATION OPTIONS

- Mounts: Base tube, vault, sled, 2-wheel cart
- Air: Hill Air
- Controls: Manual or Automated

### AUTO HYDRANT ACTUATOR OPTIONS

(for above ground hydrants or pit valve for vault)

- Communication options: standalone, hardwire or radio
- Optional onboard weather
- Optional SmartSnow integration